FUJIFILM

GFX 505

New Features Guide

Version 3.00

Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

http://www.fujifilm.com/support/digital_cameras/software/gfx_fw_table.html

Contents

GFX 50S firmware version 3.00 adds the features listed below. For information on earlier versions, visit the following website.

http://fujifilm-dsc.com/en/manual/

No.	Description	GFX 50S	See	Ver.
1	A I FOCUS BKT item has been added to drive modes.	7,81	1	3.00
2	A FOCUS BKT item has been added to SHOOTING SETTING in the shooting menu.	106	2	3.00
3	A 35mm FORMAT MODE item has been add- ed to SHOOTING SETTING > MOUNT ADAPTOR SETTING in the shooting menu.	111	3	3.00

Additions

The following features have been added.

GFX 50S Owner's Manual: 📖 7 The Drive Button

Pressing the drive button displays the following drive mode options.



Mode		Mode	
STILL IMAGE (single frame)	40	DYNAMIC RANGE BKT	81
CONTINUOUS (burst mode)	82	82 (dynamic range bracketing)	
AE BKT (exposure bracketing)	80	FOCUS BKT (focus bracketing)	—
ISO BKT (sensitivity bracketing)	80	MULTIPLE EXPOSURE	83
FILM SIMULATION BKT	80	MOVIE MOVIE	46
(film simulation bracketing)	00		1
WHITE BALANCE BKT	81		
(white balance bracketing)	01		

GFX 50S Owner's Manual: 📖 81 FOCUS BKT

Each time the shutter button is pressed, the camera takes a series of photos, varying focus with each shot. The number of shots, the amount focus changes with each shot, and the interval between shots can be selected using **SHOOTING SETTING** > **FOCUS BKT**.

GFX 50S Owner's Manual: 🗐 106 FOCUS BKT


Adjust focus bracketing settings.

Option	Description		
FRAMES Choose the number of shots.			
STEP	Choose the amount focus changes with each shot.		
INTERVAL	Choose the interval between shots.		

FOCUS BKT SETTING can also be assigned to a function button (1) 162, 182).

GFX 50S Owner's Manual: 📖 111 35mm FORMAT MODE

Enabling SHOOTING SETTING > MOUNT ADAPTOR SETTING > 35mm FORMAT MODE in the shooting menu sets the picture angle to 35 mm; the change is reflected in the display.



Option	Description	
ON	ON The picture angle is set to 35 mm; the change is re ed in the display.	
OFF	35 mm format mode disabled.	
AUTO	35 mm format mode is enabled automatically when a mount adapter that supports automatic detection is attached.	

The SCREEN SET-UP > DISP. CUSTOM SETTING item in the setup menu (19, 158) includes an option (enabled by default) for displaying a 35mm FORMAT MODE icon.

The **IMAGE QUALITY SETTING** > **IMAGE SIZE** item in the shooting menu is fixed at **I** 3:2.

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN http://www.fujifilm.com/products/digital_cameras/index.html







