FUJIFILM

GFX 505

New Features Guide

Version 3.10

Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

http://www.fujifilm.com/support/digital_cameras/software/gfx_fw_table.html

Contents

GFX 50S firmware version 3.10 adds or updates the features listed below. For information on earlier versions, visit the following website.

http://fujifilm-dsc.com/en/manual/

No.	Description	GFX 50S	See	Ver.
1	A FLICKER REDUCTION option has been add- ed to SHOOTING SETTING in the shooting menu.	109	1	3.10
2	35mm FORMAT MODE can now be assigned to a function button.	111	2	3.10
3	LARGE INDICATORS MODE(EVF) and LARGE INDICATORS MODE(LCD) options have been added to SCREEN SETTING in the setup menu.	159	3, 4	3.10
4	A LARGE INDICATORS DISP. SETTING option has been added to SCREEN SETTING in the setup menu.	159	5	3.10
5	A SELECT FOLDER option has been added to SAVE DATA SETTING in the setup menu.	171	6	3.10

Changes and Additions

Changes and additions are as follows.


GFX 50S Owner's Manual: 📖 109 FLICKER REDUCTION

Select **ON** to reduce flicker in pictures and the display when shooting under fluorescent lighting and other similar light sources.

Options				
	ON	OFF		
()	Enabling flicker reduction disables the electronic shutter and increase			
	the time needed to record pictur	es.		

GFX 50S Owner's Manual: 📖 111 35mm FORMAT MODE

35mm FORWATER Enabling ■ SHOOTING SETTING > MOUNT ADAPTOR SETTING > 35mm FORMAT MODE in the shooting menu sets the picture angle to 35 mm; the change is reflected in the display.



Option	Description	
ON	The picture angle is set to 35 mm; the change is reflected in the display.	
OFF	35 mm format mode disabled.	
AUTO	35 mm format mode is enabled automatically when a mount adapter that supports automatic detection is attached.	

The SCREEN SET-UP > DISP. CUSTOM SETTING item in the setup menu (19, 158) includes an option (enabled by default) for displaying a 35mm FORMAT MODE icon.


The **IMAGE QUALITY SETTING** > **IMAGE SIZE** item in the shooting menu is fixed at **I 3:2**.

35mm FORMAT MODE can also be assigned to a function button (E) 162, 182).

GFX 50S Owner's Manual: 📖 159 LARGE INDICATORS MODE(EVF)

and off (OFF) (162, 182).

Select **ON** to display large indicators in the electronic viewfinder. The indicators displayed can be selected using **SCREEN SETTING** > LARGE INDICATORS DISP. SETTING.



GFX 50S Owner's Manual: 📖 159 LARGE INDICATORS MODE(LCD)

Select **ON** to display large indicators in the LCD monitor. The indicators displayed can be selected using **D** SCREEN SETTING > LARGE INDICATORS DISP. SETTING.




- Some icons are not displayed when ON is selected for LARGE INDICATORS MODE(LCD), including:
 - Focus indicator

Recording levelIS mode

- Focus mode
- Distance indicator
- If LARGE INDICATORS MODE is assigned to a function button, the button can be used to toggle LARGE INDICATORS MODE on (ON) and off (OFF) () 162, 182).

GFX 50S Owner's Manual: 📖 159 LARGE INDICATORS DISP. SETTING

Choose the indicators displayed when ON is selected for ☑ SCREEN SETTING > LARGE INDICATORS MODE(EVF) or LARGE INDICATORS MODE(LCD).



Option	Description	
①Expo. DISP.	Choose the items listed at the bottom of the display. Selected items are indicated by check marks (☑); to deselect, highlight the check marks and press MENU/OK .	
② ➡ Scale	Select ON to display the exposure indicator.	
3L1, L2, L3, L4	Choose up to four large icons for display on the left side of the screen.	
④R1, R2, R3, R4	Choose up to four large icons for display on the right side of the screen.	

GFX 50S Owner's Manual: 📖 171 SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

Option	Description
SELECT FOLDER	To choose the folder in which subsequent pictures will be stored, press the selector up or down to highlight an existing folder and press MENU/OK .
	Enter a five-character folder name to create a new folder in which to store subsequent pictures.

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN http://www.fujifilm.com/products/digital_cameras/index.html







