

FUJIFILM

DIGITAL CAMERA

X-T200

New Features Guide

Version 1.10




Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

<https://fujifilm-x.com/support/download/firmware/>

Contents

X-T200 firmware version 1.10 adds or updates the features listed below. For information on earlier versions, visit the following website.

<http://fujifilm-dsc.com/en/manual/>

No.	Description	X-T200 	See 	Ver.
1	The  CONNECTION SETTING > USB IMAGE TRANSFER SETTING item in the setup menu has been renamed USB MODE and now contains an option that lets the camera serve as a webcam.	176	1	1.10

Changes and Additions

Changes and additions are as follows.







X-T200 Owner's Manual:  176

Ver. 1.10

USB MODE

Choose a mode for USB connections to computers, smartphones, and tablets.

Option	Description
USB CARD READER	Pictures can be transferred when the camera is connected to a computer, smartphone, or tablet via USB.
USB WEBCAM	When connected to a computer via USB, the camera functions as a webcam.
OFF	Data transfer is disabled when the camera is connected to a computer, smartphone, or tablet via USB.

-  Select **USB CARD READER** for **USB MODE** before connecting the USB cable to transfer pictures to a computer, smartphone, or tablet (X-T200 Owner's Manual,  205).
- Select **USB WEBCAM** for **USB MODE** before connecting the camera for use as a webcam. "FUJIFILM X-T200" will be displayed when the computer detects the camera.
- The webcam feature is supported under Windows 10 (x64), macOS 10.14 (Mojave), and macOS 10.15 (Catalina).
- When **USB WEBCAM** is selected:
 -  **IMAGE QUALITY SETTING** and  **SHOOTING SETTING** cannot be adjusted,
 - apart from the **ON/OFF** button and rear command dial (which can be used only for exposure compensation), camera controls cannot be used,
 -  **AF/MF SETTING** > **PRE-AF** is fixed at **ON** and the camera focuses only on the subject in the center focus area,
 -  **AF/MF SETTING** > **FACE/EYE DETECTION SETTING** is set to **FACE DETECTION ON**,
 - HDMI output is not available,
 - audio from built-in and external microphones is not output to the connected device,
 - images are not displayed in the LCD monitor, and
 - the AF lamp will light if the battery is low; insert a spare battery if available.
- For more information on web conferencing, see the documentation for the web conference application.

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

<https://fujifilm-x.com>

