

Automatische standkeuzehendel		●				● AUTO				● AUTO				● AUTO				AUTO	iB
Opnamestand/onderwerpprogramma		P	S	A	M	[Icon]				[Icon]				[Icon]				[Icon]	[Icon]
[Icon] SCHERPTE		✓	✓	✓	✓					✓								✓ ¹²	
[Icon] HIGHLIGHT TINT		✓	✓	✓	✓					✓								✓ ¹²	
[Icon] SCHADUWTINT		✓	✓	✓	✓					✓								✓ ¹²	
[Icon] RUISONDERDRUKKING		✓	✓	✓	✓					✓								✓ ¹²	
[Icon] L BEL. RO		✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓ ¹²	
[Icon] KIES INST. OP MAAT		✓	✓	✓	✓					✓	✓ ³								
[Icon] BEW/BEW INST. OP M		✓	✓	✓	✓					✓	✓								
PRVW BELICH HAND.					✓					✓								✓ ¹²	
SCHERPSTELLOEP (AF) ¹¹		✓ ⁶	✓ ⁸	✓ ⁶	✓ ⁶					✓ ⁶	✓ ⁶	✓ ⁶	✓ ⁶						
SCHERPSTELLOEP (MF) ¹¹		✓	✓	✓	✓					✓	✓			✓	✓	✓	✓	✓	
DISP. INST. OP MAAT	COMP.RICHTL.	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	
	ELEKTR. WATERPAS	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	
	AF-AFSTANDSINDICATOR	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	
	MF-AFSTANDSINDICATOR	✓	✓	✓	✓					✓	✓			✓	✓	✓	✓	✓	
	HISTOGRAM	✓	✓	✓	✓					✓	✓			✓	✓	✓	✓	✓	
	DIAFR/ S-SNELHEID/ISO	✓	✓	✓	✓	✓				✓							✓ ⁸		
	BELICHT. CORRECTIE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	LICHTMEETSISTEEM	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓	✓	
	FLITSLICHT	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	✓	
	WITBALANS	✓	✓	✓	✓	✓				✓								✓	
	FILMSIMULATIE	✓	✓	✓	✓	✓	✓	✓	✓			✓						✓	
	DYNAMISCH BEREIK	✓	✓	✓	✓	✓				✓									
	REST. BEELDDES	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	BEELDFORM/-KWALITEIT	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
ACCUNIVEAU	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
[Icon] KLEURR		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓ ⁹ ✓ ¹²	

- 1 Automatisch vastgesteld.
- 2 Beperkt tot bereik van $\pm 2,0$ EV tijdens filmpname.
- 3 Beschikbare opties zijn afhankelijk van de afdrukmodus.
- 4 A is niet beschikbaar.
- 5 Alleen beschikbaar voor auto ISO gevoeligheid.
- 6 Alleen beschikbaar wanneer **ENKEL PUNT** is geselecteerd voor **SCHERPSTELLING** in de scherpstelstand **S**.
- 7 Alleen beschikbaar wanneer auto standkeuzehendel is gedraaid naar **AUTO**.
- 8 Display toont alleen sluitertijd.
- 9 sRGB automatisch geselecteerd.
- 10 Flitser schakelt uit wanneer **ELEKTRONISCHE SLUITER** is geselecteerd voor **SLUITERTYPE**.
- 11 De zelfontspanner wordt automatisch uitgeschakeld wanneer de intervaltimer is ingeschakeld.
- 12 Instellingen stiltefoto worden gebruikt.
- 13 Draadloos op afstand fotograferen.